



**GENERAL NOTE(S):**

1. GRAVITY PIPE PASSES THROUGH MANHOLE. REMOVE ITS TOP HALF.

**KEYED NOTE(S):**

- ① BEFORE CUTTING PIPE, INSTALL BRICK/MORTAR MIXTURE FROM MANHOLE BOTTOM TO PIPE CENTERLINE. SLOPE TO PIPE CENTERLINE.
- ② TYPES 2 OR 3 APPLICATION ONLY: BEFORE CUTTING PIPE, COAT BRICK/MORTAR MIXTURE WITH RAVEN 405 EPOXY COATING. ALSO COAT MANHOLE BOTTOM AND PIPE PENETRATIONS.
- ③ CUT AND REMOVE TOP HALF (CENTERLINE) OF (PVC) PIPE. START CUT 3-INCHES FROM MANHOLE WALL.

**216**

**GRAVITY PIPE THROUGH STANDARD  
MANHOLE, LONGITUDINAL VIEW**

**NTS**

