



GENERAL NOTES:

- A. CUT AND REMOVE SEGMENT OF EXISTING CLAY PIPE.
- B. INSTALL WYE. FASTEN WITH STRONG-BACK COUPLING.
- C. CLEAN AND SOLVENT WELD ALL SOCKET FITTINGS.
- D. IF BELL PRESENT, CENTER INSTALLATION ON BELL THEN REMOVE BELL.

KEYED NOTES:

- ① CONNECT PIPE TO BOTTOM OF CLEAN-OUT. DO NOT CONNECT PIPE TO RISER SECTION OF CLEAN-OUT.
- ② INSTALL WYE SO ITS BRANCH IS 45° ABOVE HORIZONTAL.
- ③ INCLUDES CLAMP AND SHEAR RING.

251

**INSTALLING SERVICE LATERALS IN EXISTING
CLAY GRAVITY WASTEWATER MAINS**

NTS

