



**GENERAL NOTES:**

- A. CUT AND REMOVE SEGMENT OF EXISTING PVC PIPE.
- B. INSTALL WYE. FASTEN WITH GASKET REPAIR COUPLING.
- C. CLEAN AND SOLVENT WELD ALL SOCKET FITTINGS
- D. IF BELL PRESENT, CENTER INSTALLATION ON BELL. THEN REMOVE BELL.

**KEYED NOTES:**

- ① CONNECT PIPE TO BOTTOM OF CLEAN-OUT. DO NOT CONNECT PIPE TO RISER SECTION OF CLEAN-OUT.
- ② INSTALL WYE SO ITS BRANCH IS 45° ABOVE HORIZONTAL.

**254**

**INSTALLING SERVICE LATERALS IN  
EXISTING PVC SDR 35 GRAVITY  
WASTEWATER MAINS**

**NTS**

