



GENERAL NOTES:

- A. REMOVE EXISTING CAPS FROM EXISTING STUB-OUTS.
- B. IT IS ASSUMED THAT EXISTING LATERAL STUB-OUTS ARE INSTALLED AT 45° ABOVE HORIZONTAL. IF NOT, CONTACT THE ENGINEER OR CITY.
- C. CLEAN EXISTING STUB-OUT AND NEW PIPE PRIOR TO SOLVENT WELDING.
- D. SOLVENT WELD ALL PVC CONNECTIONS.

KEYED NOTES:

- ① CONNECT PIPE TO BOTTOM OF CLEAN-OUT. DO NOT CONNECT PIPE TO RISER SECTION OF CLEAN-OUT.