



**GENERAL NOTES: SEE 321A**

KEYED NOTE(S):

- ① IF NO VALVE, THEN INSTALL AN APG, SIMILAR TO 318.
- ② PROVIDE APG (GROUNDING NOT REQUIRED) IF DISCHARGE VALVE IS ABOVE GRADE. INSTALL SIMILAR TO 318. IF DISCHARGE VALVE IS IN A VAULT, THEN PROVIDE ENOUGH TRACER WIRE SO IT CAN EXTEND 8-INCHES ABOVE VAULT COVER.

**321C**

**WASTEWATER FORCE MAIN TRACER  
WIRE CONFIGURATION  
NTS**

