

NOTES:

- 1. CONTRACTOR SHALL LOCATE LOAD-SIDE CONDUIT ON RIGHT SIDE OF SOCKET, LINE-SIDE CONDUIT ON THE LEFT.
- 2. CONTRACTOR SHALL FURNISH AND INSTALL SERVICE CONDUIT TO SERVICE PEDESTAL OR TRANSFORMER.



TYPICAL RESIDENTIAL SINGLE FAMILY DETACHED UNDERGROUND INSTALLATION NTS

